






ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE



Please install the Anti tipping hardware as shown in the drawing—this can help to prevent any tipping issues.


Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	SIZE	QTY
1	PLUG			2PCS
2	LARGE SCREW		ø8*2"	1PC
3	TIGHTWIRE			1PC
4	SHORT SCREW		ø8*3/4"	1PC



ASSEMBLY TIME PER UNIT: 3MINUTES

ATTENTION:Anti tipping safeguard



FURNITURE TIPPING RESTRAINT

WARNING

Injury may occur from furniture tipping. This restraint is not a substitute for proper adult supervision. DO NOT allow children from climbing the furniture. The Furniture Anti Tipping information is provided to help the furniture from moving. When you decide to move the furniture again, REMOVE the restraint from the wall. This will help with make sure that no injury occurs and/or damage.