

**COASTER**<sup>®</sup>  
FINE FURNITURE

300257T  
TWIN SIZE  
HEADBOARD&FOOTBOARD

ASSEMBLY INSTRUCTION  
COASTER FINE FURNITURE



[www.coastercompany.com](http://www.coastercompany.com)

08/07/2014

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




### Warning !

1. Don't attempt to repair modify parts that are broken or defective . Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.


## PARTS IDENTIFICATION:

## Z HARDWARE LIST:



A HEADBOARD

1pc










B FOOTBOARD

1pc




C LEG

2pcs

NO	DESCRIPTION	FIGURE	QTY
1	LARGE BOLT		4PCS
2	SMALL BOLT		4PCS
3	METAL WASHER		8PCS
4	PVC WASHER		8PCS
5	HEX. NUT		4PCS
6	ALLEN WRENCH		1PC
7	WRENCH (11.3mm)		1PC

STEP 1:Align and attach the legs (C) to the headboard (A) then attach the side rails by using the bolt(1), pvc washer (4), metal washer (3), hex nut (5) and tighten with the allen wrench and wrench.



STEP 2:Align and attach the footboard (B) to the side rails by using the bolt(2), pvc washer (4), metal washer (3) and tighten with the allen wrench.

