


Exploded view



RA31B3S Parts List

No.	Part Code	Description of Spare Part	Qty
2	20122080036	Door hinge screw hole cover	1
3	20122080091	Door hinge cover	1
4	3031400148	Upper hinge assembly	1
5	20122990103	Ice cube tray	1
6	20101060400	Upper door	1
6.1	3020400145	Upper door gasket	1
6.2	20122090005	Right limit block of door	1
6.3	20122090011	Left limit block of door	1
7	3020500092	Upper door bar	1
8	2207500509	Upper rack,left	1
9	2207500510	Lower rack,left	1
10	20122050767	Cola rack	3
11	2100150768	Lower door	1
11.1	3020400146	Lower door gasket	1
11.2	20122090161	Lower door right aid-closer	1
11.3	20122090178	Lower door left aid-closer	1
19	20122040254	Crisper Drawer	1
20	20120030010	Crisper box cover	1
21	3039900264	Compressor support base	1
22	3050100117	Power supply cord	1
23	3040500011	Drier filter	1
24	20114070006	Connecting tube	1
25	3040100320	Compressor	1
26	3050200095	Earthing wire of compressor	1
28	3040600005	Process tube	1
31	20122990019	Long adjustable foot	1
32	20122990006	Short adjustable foot	1
33	20120020042	Shelf of refrigerator chamber assembly	1
34	3031400067	Lower door hinge assembly	1
35.1	20122010048	Lamp cover	1
35.2	2500500002	Lamp bulb	1
35.3	20122010037	Thermostat knob	1
35.4	20122010002	Thermostat cover	1
35.5	2400200005	Thermostat	1
35.6	2500600001	Lamp holder	1
41	3059900015	Door switch	1
42	20122990039	Drain pan	1
43	3031400116	Middle door hinge assembly	1