



FF10B3S Parts List

No.	Part code	Description of Spare Part	Quantity
1	20122990103	Ice cube tray	1
2	2208100413	Cover of door hinge screw hole	1
3	3031400197	Upper door hinge	1
4	2208200084	Upper door hinge,left	1
5	2208100412	Upper door hinge,right	1
6	3031400040	Middle door hinge	1
8	2106100012	Shelves of freezer chamber	1
9	3039900316	Water channel of drain heater	1
10	3040300075	Fin evaporator	1
11	2500700006	Defrost heater	1
12	3050200087	Connecting wire of temperature sensor	1
13	2107120016	Freezing wind tunnel part	1
13.1	20122990721	Installation cover of electrical motor	1
13.2	3059900004	Fan motor assembly of freeze wind tunnel part	1
13.3	2209100065	Rear cover of freeze wind tunnel part	1
13.4	3071000311	Foam of freeze wind part	1
13.5	2208200085	Adjust catch of freeze wind tunnel part	1
13.6	2208200052	Front cover of freeze wind tunnel part	1
13.7	2208100219	Knob of freeze wind tunnel part	1
24	2100290153	Upper door	1
24.1	2200200084	Upper door gasket	1
24.2	3029900431	Inner door gasket	1
24.3	2208510008	Right limit block,upper door	1
24.4	2208510007	Left limit block,upper door	1
25	2207500358	Door rack,freeze	2
27	2107120017	Refrigerate wind tunnel part	1
27.1	2701000139	Foaming parts of refrigerate wind tunnel part,upper	1
27.2	2701000140	Foaming parts of refrigerate wind tunnel part,lower	1
27.3	2208200051	Installation cover of electric control board	1
27.4	2500300019	Electric control board	1
27.5	2208200050	Installation box of electric control board	1
27.6	2208200117	Front cover of refrigerator wind tunnel part	1

No.	Part code	Description of Spare Part	Quantity
27.7	3050400025	LED Light	1
27.8	2209100066	Lamp cover	1
27.9	20122990726	Water rack	1
27.10	2209100059	Display pannel	1
27.11	2500200024	Connecting wire of refrigerator (weak current)	1
27.12	2500200025	Connecting wire of refrigerator (strong current)	1
30	2207500360	Lower door rack cover	1
31	2207500359	Lower door rack,upper	1
32	2207500361	Lower door rack,middle	1
34	2207500363	Code rack	2
37	2207500362	Lower door rack,lower	1
39	2100290154	Lower door	1
39.1	2200200085	Lower door gasket	1
39.2	2208510013	Right aid-closer,lower door	1
39.3	2208510020	Left aid-closer,lower door	1
41	2207600003	Shelf of refrigerator chamber	2
42	2106120041	Cover of crisper drawer	1
43	2207400156	Crisper drawer	2
45	3031400204	Lower door hinge assembly , right	1
46	20122990026	Short adjust leg	1
47	3031400205	Lower door hinge assembly,left	1
48	2207700062	long adjust leg	1
52	2107100002	Compressor support base	1
53	3050100117	Power supply cord plug	1
57	2400100064	Compressor	1
58	3040600005	Process tube	1
62	3040500011	Drier filter	1
63	20122990705	Drain pan	1
64	20114010106	Evaporative condenser	1
65	2207700024	Drain pipe	1
66	20114070006	Connecting tube	1
67	3050200095	Earthing wire of compressor	1
68	2501100002	Door switch	1