



# LG HA NEWSWIRE

Key points you can use to talk, train, teach

## Sabbath Mode: LG Cooking & Refrigeration

Sabbath mode is used on the Jewish Sabbath and Holidays and requires a restriction on certain activities during these times. LG offers a growing variety of ranges, wall ovens, and refrigerators that feature Sabbath Mode. Most new product introductions will include Sabbath Mode where applicable.

You'll find that demand for this feature is higher in the Northeast, Illinois, and California.



### Setting Sabbath Mode For Ranges & Wall Ovens



#### For ranges:

1. Disconnect meat probe from equipped models (not useable with Sabbath Mode)
2. Select **BAKE** mode for the oven, set desired temperature, and cooking time (up to 12 hrs.), and press **START**. (Sabbath mode only available when oven is in **Bake** mode)
3. Press-N-Hold **START** for 3 seconds. "Sb" will appear indicating Sabbath Mode is activated. Repeat to deactivate. You can use the SmartThinQ™ app for wi-fi enabled models to turn on Sabbath Mode.
4. Repeat (step 3) to deactivate Sabbath Mode

#### For wall ovens, follow steps 1-2 above, then:

3a) Press-N-Hold **MORE MODE** for 3 seconds. "Sb" will appear indicating Sabbath Mode is activated. Repeat this step to deactivate.

You can use the SmartThinQ™ app for wi-fi enabled models to turn on Sabbath Mode. Sabbath Mode will be maintained even after a power outage, but the oven will be off.



Range Control Panel

While the oven is in Sabbath mode, the following functions are disabled:


- Temperature Adjustments (oven)
- Cooking Timer
- Display
- Oven Light On/Off
- Alarm Functions
- Wi-fi



### Setting Sabbath Mode on Refrigerators

1. Press-N-Hold the SMART GRID & FREEZER buttons together for 3 seconds, or use the SmartThinQ™ app for wi-fi enabled models.
2. Repeat the process to turn off Sabbath Mode. *(This could be demonstrated on the sales floor)*

After 96 hours, Sabbath mode will automatically turn off or manually from the control panel (step 2). Once turned on, Sabbath Mode will be maintained even after a power outage.



Refrigerator Control Panel

While the refrigerator is in Sabbath mode, the following functions are disabled:

- Temperature Adjustments
- Lighting (including InstaView™)
- Alarm Functions
- Ice & Water Dispenser
- Wi-fi

#### COOKING

##### Models:

LWC3063\_  
LSD4913ST  
LSG4515\_  
LSE4615\_  
LSSG3017ST  
LSSG3020BD  
LSSE3027ST  
LSSE3030BD

#### REFRIGERATION

##### Models:

LFXS28596  
LFXS26973  
LFXS26566  
LFXS26596  
LFXC22526  
LFXC22596