



# WCF154S3SD Parts List

No.	Parts#	Part Name	Qty
1	US3-23	Water tank	1
2	US2-14	Strainer	1
3	US1-32	Power cord	1
4	US1-40	Compressor(NS1114HY)	1
5	US3-14	The cover of power box	1
6	US5-1	Power PCB	1
7	US3-13	Power box	1
8	US3-48	The cover of the hinge screw hole.	5
9	US3-27	The cover of hinge	1
10	US4-16	Upper hinge	1
11	US2-21	Copper Evaporator	1
12	US1-6	The fan of evaporator	1
13	US3-24	Inner water tank	2
14	US3-86	The carbon filter	1
15	US3-16	The back air-duct Board	1
	US4-94	fan net	2
16	US1-9	The upper sensor	1
17	US3-49	The cover of the sensor	1
18	US1-28-W	Light	3
19	US3-12	Light cover	3
20	US4-116	The middle air-duct upper board	1
21	US5-5	Control PCB	1
22	US3-63	The control panel box	1
23	BZ1-126	Sticker	1
24	MT07-8	Door with handle/gasket	1
25	US4-14	The lower supporter of the door	1
26	US3-10	Small shelf	1
27	US3-8	Big shelf	13
28	US4-95	The small rolling guide	2
29	US4-49	The big rolling guide(Two Section)	10
	US4-96	The big rolling guide(Three Section)	16
30	US4-117	The middle air-duct board	1
31	US1-6	The middle fans	2
32	US1-10	The lower sensor	1
33	US1-7	Heating fan	1
34	US1-17	Heater	1
35	US4-105	The front vent (stainless steel)	1
36	US1-15	Lower hinger	1
37	US2-18	Condensor	1
38	US4-56	The fix plate	1
39	US3-45	feet	4
40	US2-12	Circle pipe	1
41	US1-34	Bracket for fan	2
42	US4-52	The fan of condensor	1
43	US4-27	The bottom plate	1