




## **30" GAS COOKTOP**

### **MODELS:**

WCG55US0HB00 (Black)

WCG55US0HW00 (White)


# COOKTOP, BURNER AND GRATE PARTS



# COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286813	Head, Burner (Left Front)	13		Hinge, Grate (Not Serviced)
	W11116971	Instructions, Installation		8286815	Head, Burner (Left Rear & Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W10672375	Instructions, Undercounter Install		8286814	Head, Burner (Right Front)	W10868534		Harness (Switch), Main
	W11120470	Guide, Use & Care	9		Grommet	W10392003		Cord, Power
	W11168236	Instructions, LP Conversion		W10625915	Black	W10132200		Relief, Strain
2		Cooktop		W10614849	Grey	313438		Clip, Harness
	W11131854	Black	10	8286921	Screw, Burner Rail (M4)	W11173306		Kit, LP Conversion
	W11131856	White				3801F935-51		Bracket, Tie Down
3		Kit, Burner Cap	11	W10652711	Orifice (Left Front)	7101P062-60		Screw (For Tie Down Bracket)
	W10597129	Black		W10609592	Orifice (Left Rear)			
4		Kit, Grate		W10652710	Orifice (Right Front)			
	W11047087	Black		W10409144	Orifice (Right Rear)			
5	8286863	Spring, Electrode	12	W10541842	Wiring, Electrode (Left Front & Right Front)			
6		Knobs, Cooktop		W10541843	Wiring, Electrode (Left Rear & Right Rear)			
	W11084622	Black						
	W11084621	White						
7	W10594399	Holder, Orifice (5K) (Left Front)						
	W10609591	Holder, Orifice (15K) (Left Rear)						
	W10594402	Holder, Orifice (9.1K) (Right Front)						
	W10597159	Holder, Orifice (12K) (Right Rear)						

# BURNER BOX, GAS VALVES AND SWITCH PARTS



# BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8287057	Screw, Valve Bracket	7	W10449143	Regulator, Pressure	14	W10566289	Tubing, Gas Burner
2	W10594394	Assembly, Manifold	8	W10594429	Bracket, Orifice Holder			(Right Rear)
3	W10597157	Valve, Single (Left Front)	9	W10475148	Module, Spark	15	7101P426-60	Screw
	W10594391	Valve, Single (Left Rear & Right Rear)	10		Box, Burner (Not Serviced)			OPTIONAL PARTS (NOT INCLUDED)
	W10594393	Valve, Single (Right Front)	11	W10566287	Tubing, Gas Burner (Left Front)		W10685483	Griddle Knobs
4	8287055	Bracket, Single Valve	12	W10566288	Tubing, Gas Burner (Left Rear)		W10698166	Stainless Kit, Grates
5	W10140571	Seal, Switch Shaft	13	W10566290	Tubing, Gas Burner (Right Front)		W10594440	Gray
6	W10614950	Panel, Front						